ACCUSPLIT®

ACCUSPLIT.

PRO SURVIVOR™

PRO SPLIT STOPWATCH

STOPWATCH OPERATIONS

SINGLE EVENTS
R – START
R – STOP
L – RESET

TIME-IN, TIME-OUT
R – START
R – STOP
R – RESTART
R – STOP
L – RESET

LAP SPLIT
C – PUSH AND RELEASE UNTIL "LAP" APPEARS
R – START
L – SPLIT
L – RETURN TO RUNNING TIME
R – STOP
L – RESET

CUMULATIVE SPLIT
C – PUSH AND RELEASE UNTIL "CUM" APPEARS
R – START
L – SPLIT
L – RETURN TO RUNNING TIME
R – STOP
L – RESET

1,2 FASH FINISH
C – PUSH AND RELEASE UNTIL "CUM" APPEARS
R – START
L – FINISH #1
R – FINISH #2
L – DISPLAY #2
L – RESET

BATTERY CHANGING
See Specifications panel and drawing to right.



REGISTER NOW Please return your Survivor Stopwatch Registration to the Repair Center address in the warranty, & we will let you know about future products.

Email (preferred)_____
User_____

SPECIFICATIONS

Batteries: Batteries should last for 18 months. If display becomes dim, open back and replace with Duracell LR43, Eveready 186, or Ray-O-Vac LR43.

Operating Temperature: 14°F to 138°F (–10°C to 59°C).

Quartz Crystal Accuracy: 0.04 sec/hr (accuracy may vary with shock, temperature or aging of crystal).

NO-PROOF-OF-PURCHASE LIMITED WARRANTY
See label on back of unit for details, or check http://support.ACCUSPLIT.com

1-800-965-2008 or 1-925-226-0888
FAX: 925-463-0147
support@accusplit.com
www.accusplit.com

ASSEMBLED IN PRChina
© 2005 ACCUSPLIT

ACCUSPLIT, Inc.
6120 Stoneridge Mall Rd.
Suite 210
Pleasanton, CA 94588 USA
800-965-2008 • 925-226-0888
FAX 925-463-0147
www.ACCUSPLIT.com
support@ACCUSPLIT.com

Downloaded from www.Manualslib.com manuals search engine